



**The ez
Guide**

Model # UVC 3022

99.9% sterilizing rate



How to setup:

Step 1: Charge the UV Light Lamp before first use “RED light” Means charging and “green light” full charged.

Step 2: Press on the power ON/OFF for 3 seconds to turn unit ON.

Step 3: slowly move UV light over any surface/object you want to Sterilization for 10 to 300 seconds.

Step 4: You can manually turn it off by pressing the ON/OFF button.

Benefits

- 2 Led for Light weight Pocket size
- Fast acting and efficient 99.9% sterilization
- Eliminate a variety of Pathogens
- Sterilization without use of harmful chemicals that leave residue.
- Portable and Rechargeable USB charging
- Lightweight pocket size

Suggestions

- Note that the effectiveness of UV disinfection depends on having an uninterrupted line-of-sight exposure.
- Disinfect computers keyboards, phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, toothbrushes, remotes, eye glasses, makeup brush, hair brush, hearing aids.

Caution and Warnings

- Do not directly look at UV light when sanitization is in progress.
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- This equipment is intended for indoor use only
- Do not alter the device.
- Do not use this Lamp for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Lamp if any damage to the unit is visible or suspected.

Maintenance

Keep the UV Sterilizer clean you can gentle wipe it with soft cloth