



The ez Guide
Model # UVC 3043

99.9% sterilizing rate



How to setup:

Step 1: Charge the unit through the charging port located on the bottom of the unit for 2 hours before first use

Step 2: Press and hold the power button located on bottom of the unit and wait for 10 seconds to turn on

Step 3: Leave it to a place for eradication

Step 4: Press and hold the power button located on bottom of the unit again to turn off

Note: It will automatically turn off after 30 minutes
 Please note: Make sure the unit is always charged before eradication

Benefits

- UV-C and Ozone for double sterilization
- Eliminate odor
- Rechargeable light weight and easy to transport
- Fast acting and efficient sterilization, eliminate a variety of Pathogens
- Free from chemical agents
- Auto Stop Timer

Suggestions

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of-sight exposure.
- Place the UV Sterilizer within a particular line-of-sight that offers optimum results.
- Best Use: fridge, small cupboard, draw, cabinet, car, van, limos. Turn your shoe box into disinfection box to do cash, wallets, keys, masks, jewelry, watches, socks, headphones, toothbrushes, hearing aids, remotes, eye glasses

Caution and Warnings

- Do not look at the light source with naked eye; avoid light from falling on skin
- Do not breath Ozone, always ventilate area before entering area that was purified/sanitized with Ozone
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Sterilizer for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Sterilizer if any damage to the unit is visible or suspected
- Do not alter the device

Maintenance

Keep the UV Sterilizer clean you can gentle wipe it with soft cloth