



How to setup:

99.9% sterilizing rate

Model # UVC 3059

The ez

Guide

Model # UVC 3059
Sterilization mode: ultraviolet C Wavelength: 200-280nm UV Radiation Type: UV C Bulb shape: Tube Tube Material: Quartz Wireless charging: 5W Utility model patent certificate, appearance patent certificate, test report, CE, FCC, ROHS No Chemicals No Chemicals
No Chemical Smell
100nm 2280 315 400 800nm UVC UVB UVA Visible Eight Wavelength https://uvcanada.ca

Step 1: Plug in charging wire into the charging port located on back of the unit

Step 2: Place item into the box close lid

Step 3: Drop 3-5 drops of preferred aroma into the diffuser inlet to use the aromatherapy diffuser (optional)

Step 4: Press the UV button (Disinfection) or Wind button (Aromatherapy) in front of the unit to turn on and begin the process

Note: Flashing blue light indicate UVC function is off while solid blue light indicates the function is on and working
Note: Flashing red light indicate Wind function is off while solid red light indicates the function is on and working
Step 5: Press the UV button (Disinfection) or Wind button (Aromatherapy) in front of the unit again to turn off the unit
Note: Unplugging the charging wire will turn off the unit
Note: The unit will also turn off automatically after 5 minutes

Benefits

- Fast and effective UV-C disinfection
- Eliminate bacteria and viruses 99.9% clean in seconds
- Added advantage of build in aromatherapy diffuser & amp; Fast Phone charging USB charger
- Fill it with everything that fit in
- Built in Fast Phone USB charger
- Auto Stop Timer

Suggestions

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of sight exposure.
- Best Use: Phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, toothbrushes, Makeup brush, hair brush, hearing aids, remotes, eye glasses & amp; more

Caution and Warnings

- Do not look at the light source with naked eye; avoid light from falling on skin
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Box for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Box if any damage to the unit is visible or suspected
- Do not alter the device
- This equipment is intended for indoor use only

Maintenance

Keep the UV Box clean you can gentle wipe it with soft cloth

Copyright© ez technology Canada 2020