



**The ez  
Guide**

**Model # UVC 3076**

**How to setup:**

**99.9% sterilizing rate**



**Step 1:** Charge the product through the charging port for 2-3 hours before first use

**Note:** The indicator light is solid blue when the unit is fully charged

**Step 2:** Press and hold the power button (Black Button) located on the top of the unit for 3 seconds to turn on the unit

**Note:** The unit will “Beep” once and begin its count down from 180 seconds

**Note:** When timer is up, the unit turns off automatically

**Step 3:** Scan the area with light turned on; the closer it is, the faster eradication takes place

**Step 4:** Press the power button again to turn off the unit

**Note:** The unit will “beep” twice before it turns off

**Benefits**

- Rechargeable, light weight and easy to carry
- UV-C disinfection technology
- Free from chemical agents
- Removes harmful particles from surfaces, eliminate bacteria and viruses 99.9% Clean
- Ozone-Free
- Digital display and auto timer

**Suggestions**

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of sight exposure
- Place the UV light within a particular line-of sight that offers optimum results.
- Best Use: Phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, tooth-brushes, remotes, eye glasses, makeup brush, hair brush, hearing aids and more

**Caution and Warnings**

- Do not look at the light source with naked eye; avoid light from falling on skin
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Sterilizer for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Sterilizer if any damage to the unit is visible or suspected
- Do not alter the device
- This equipment is intended for indoor use only

**Maintenance**

Keep the UV Sterilizer clean you can gentle wipe it with soft cloth