

**Model # UVC 3085** 

99.9% sterilizing rate

Model # UVC 3085

Sterilization mode: ultraviolet C & A



# How to setup:

**Step 1:** Plug charging wire into the charging port located on lower back of the unit to turn on

Step 2: Place the item into the unit

**Step 3:** Press the power button located on the bottom right corner of the unit to start the eradication process

**Step 4:** The green light will turn on indicating that the eradication process has begun

**Note:** The disinfection process will discontinue if the lid is not covered properly

**Step 5:** The unit will "Beep" three time and turn off after 5 minutes, indicating the eradication process has finished

Step 6: Unplug the charging wire to turn off the unit

#### Wavelength: 200-375nm UV Radiation Type: UV C + UV A Bulb Type: 6 x LED LED TYPE: 2 x UVC LED + 4 x UVA LED Auto Stop Timer: Yes Power port: USB No Chemical Residue No Chemical Smell No Chemical Smell UVC UVB 400 Kolone Visible Lipho V

# **Benefits**

User-friendly

The ez

Guide

- Fast and effective UV-C disinfection
- Eliminate bacteria and viruses 99.9% Clean
- Added advantage of build in aromatherapy diffuser.
- Fill it with everything that fit in
- Built in Fast Phone USB charger
- Auto Stop Timer

### **Suggestions**

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of-sight exposure.
- Best Use: Phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, toothbrushes, Makeup brush, hair brush, hearing aids, remotes, eye glasses & amp; more

# **Caution and Warnings**

- Do not look at the light source with naked eye; avoid light from falling on skin
- Do not breath Ozone, always ventilate area before entering area that was purified/sanitized with Ozone
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Box for other than its intended purpose, as described in suggestions
- · Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Box if any damage to the unit is visible or suspected
- Do not alter the device

#### Maintenance

Keep the UV Box clean you can gentle wipe it with soft cloth

Copyright© ez technology Canada 2020