



The ez Guide Model # UVC 3075

99.9% sterilizing rate

	Model # UVC 3075
Ľ	
S	terilization mode: ultraviolet C
V	Vavelength: 200-280nm
U	JV Radiation Type: UV C
L	ED TYPE: 6 x UV C LED
Α	wailable color: Pink - Blue
S	terilization Time: 3 minutes and 8 minutes
Ρ	ower interface: Type-C
Ρ	lower: USB
	No Chemicals
	No Chemical Residue
	No Chemical Smell
1	
-	
	100nm 280 315 400 800nm
	UVC UVB UVA Visible Light
	Wavelength
	https://uvcanada.ca

How to setup:

Step 1: Plug charging wire into the charging port located on lower back of the unit to turn on

Step 2: Open the zipper and place items within

Note: Avoid stacking and only put in dry items

Step 3: Close the zipper

Step 4: Press the power button to begin the disinfection process

Note: The unit will "Beep" once if the power button is pressed once for "quick disinfection mode" that will last for 3 minutes **Note:** The unit will "Beep" twice if the power button is pressed again, and the disinfection process will last for 8 minutes **Step 5:** The unit will "Beep" three times when the disinfection process is completed

Note: The disinfection process will discontinue when the magnetic switch is not put on properly

Step 6: Unplug the charging wire to turn off the unit

Benefits

Suggestions

- Portable high quality material
- Fast and effective UV disinfection
- User-friendly
- Eliminate bacteria and viruses in seconds
- Fill it with everything that fit in
- Auto Stop Timer

 Best Use: Baby Stuff, Lingerie, makeup brushes, barber tools and anything that you can fit in.

Caution and Warnings

- Do not look at the light source with naked eye; avoid light from falling on skin
- · Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Box for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Box if any damage to the unit is visible or suspected
- Do not alter the device
- This equipment is intended for indoor use only

Maintenance

Keep the UV Box clean you can gentle wipe it with soft cloth

Copyright© ez technology Canada 2020