


**The ez  
Guide**

**Model # UVC 3011**

**How to setup:**

**99.9% sterilizing rate**



**Step 1:** Plug UV box to power using USB cable provided, blue lite will start

flashing, box is ready to use

**Step 2:** Open top cover of box and place whatever you can fit in it.

**Step 3:** Close cover and tap on the touch sensitive power ON/OFF button

the flashing blue light will turn solid blue and you will hear a beep box is now in sterilization mode.

**Step 4:** Your UV box is equipped with a smart timer It will auto shut-off after 6 minutes.

**Step 5:** You can also manually turn it off by tapping on the touch sensitive ON/OFF switch

**Step 6:** you can take advantage of the fast charging USB port inside the box to charge your phone while it is been sanitized inside the box, or take advantage of the build in aromatherapy diffuser.

**Benefits**

- Unique and simple mode of operation
- Fast acting and efficient 99.9% sterilization
- UV-C Disinfection technology
- Sterilization without chemicals no chemical residue or smell
- Build in aromatherapy diffuser.
- Fast Phone charging USB port
- Auto Stop Timer

**Suggestions**

- Note that the effectiveness of UV disinfection depends on having an uninterrupted line-of-sight exposure.
- Best Use: Phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, tooth-brushes, Makeup brush, hair brush, hearing aids, remotes, eye glasses & more

**Caution and Warnings**

- Do not open box when sanitization is in progress.
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- This equipment is intended for indoor use only
- Do not alter the device.
- Do not use this Lamp for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Lamp if any damage to the unit is visible or suspected.

**Maintenance**

Keep the UV Box clean you can gentle wipe it with soft cloth