


The ez Guide

Model # UVC 3029

99.9% sterilizing rate



How to setup:

Step 1: Charge the unit through the charging port located on the bottom of the unit for 2 hours before first use

Step 2: Tap the dimmer located on top of the unit to turn on

Step 3: Scan the area with light turned on; the closer it is, the faster eradication takes place

Step 4: Tap the dimmer again to turn off the unit

*** Please note:** Make sure the unit is always charged before eradication

Benefits

- Eliminate a variety of Pathogens
- Removes harmful particles from surfaces
- UV-A and UV-B LED new technology
- Kills up to 99.9% of microbiomes in less than 10 seconds
- 22 LED footprint, for quick results.

Suggestions

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of sight exposure.
- Place the UV Tube within a particular line-of sight that offers optimum results.
- Best Use: Food, Bed sheet, curtains, furniture's, kid's toys, pet toys, laundry, kitchen counter, retail shop inventory & more

Caution and Warnings

- Do not look at the light source with naked eye; avoid light from falling on skin
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Tube for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Tube if any damage to the unit is visible or suspected
- Do not alter the device
- This equipment is intended for indoor use only

Maintenance

Keep the UV Tube clean you can gentle wipe it with soft cloth