


**The ez
Guide**

Model # UVC 3060

How to setup:

99.9% sterilizing rate



Step 1: Plug in charging wire into the charging port located on side of the unit

Step 2: Place item into the box close lid

Step 3: Press and hold the power button (Pink - White or Green Button) located on the top of unit for 2 seconds. The UV light will turn on when red light lights up

Step 4: Press and hold the power button again to turn off. When the red light stops flashing, it indicates that the eradication process has stopped.

Step 5: Unplug the charging wire to turn off the unit

Benefits

- User-friendly digital control panel
- Fast and effective UV-C & UV-disinfection
- Eliminate bacteria and viruses 99.9% Clean
- Added advantage Wireless fast charging.
- Fill it with everything that fit in
- Portable makeup mirror
- Auto Stop Timer

Suggestions

- Note that the effectiveness of the UV light sterilization depends on having an uninterrupted line-of sight exposure.
- Best Use: Phone, cash, wallets, keys, masks, jewelry, watches, socks, headphones, toothbrushes, Makeup brush, hair brush, hearing aids, remotes, eye glasses & more

Caution and Warnings

- Do not look at the light source with naked eye; avoid light from falling on skin
- Avoid exposure to UV rays, it can be harmful to the eyes and skin
- Do not use this Box for other than its intended purpose, as described in suggestions
- Equipment should be protected from the elements and from temperatures below freezing
- Do not operate the UV Box if any damage to the unit is visible or suspected
- Do not alter the device
- This equipment is intended for indoor use only

Maintenance

Keep the UV Box clean you can gentle wipe it with soft cloth